



Grumek Shackle

OPERATION & MAINTENANCE MANUAL

GRUMEK SHACKLE – OPERATION & MAINTENACE MANUAL



TABLE OF CONTENTS

1	INTRODUCTION	2
1.1	GENERAL	
2	EQUIPMENT DESCRIPTION	2
2.1	DIMENSIONS AND WEIGHT	2
3 4	OPERATION 3 MAINTENANCE	5
4.1 4.2	GENERALINSPECTION	5
5	APPENDEDIX 6	
5.1 5.2	APPENDIX 1 GRUMEK SHACKLE DRAWING – 001-2018-03	



1 INTRODUCTION

1.1 GENERAL


The purpose of this document is to provide instructions to safely operate and maintain the Grumek Shackle.

This manual is to be used by competent personnel that have proper training in usage and maintenance of lifting equipment.

2 EQUIPMENT DESCRIPTION

2.1 DIMENSIONS AND WEIGHT

Description	Value
WLL	25Te
Length	615mm
Width (Ø)	412mm
Height	415mm
Weight in air	49kg
Weight submerged in water	42kg







Figure 2-1: Grumek Shackle dimensions



3 OPERATION

Grumek Shackle operation


1. Pull **Orange** rope to the right to unlock shackle



2. Shackle lock is open



3. Pull on **Yellow** rope to the right to retract shackle pin



4. Shackle-pin retracted and in position for connection

Warning:


Never put hand inside shackle when spring is loaded!






5. Insert Masterlink into shackle and push on the spring-loaded shackle-pin releaser


6. Shackle pin is released and engaged






7. Pull **Orange** rope to the left to lock Shackle







9. Pull on Yellow rope to confirm shackle pin is locked. Grumek Shackle is locked and ready for lifting.





4 MAINTENANCE

4.1 GENERAL

Proper care and maintenance of the Grumek Shackle will give a long lifetime and maintain the safety for use of the shackle.

After usage the shackle should always be cleaned, inspected and preserved for future usage. Always ensure to:

- Flush probably in fresh water, preferably fully submerged in a small tank of fresh water
- Clean out any debris such as sand, mud, marine growth etc.
- Spray moving parts with a corrosion inhibitor such as WD40 or similar

Important: Always store the Grumek Shackle with the shackle-pin engaged (shackle-pin spring is than unloaded), see step 5. This to avoid the spring weaken over time.

4.2 INSPECTION


Prior to and after every usage of the Grumek Shackle, always inspect for any visual damage. Function test all functions to ensure a safe operation.

Important: If any significant damage is found, do not use the shackle before an inspection and/or testing have been carried out by an authorised person. If in doubt, contact Grumek Subsea AS.

Yearly inspection and re-certification is to be carried out by a certified lifting authorised company.



5 APPENDEDIX





5.2 APPENDIX 2 LOAD TEST CERTIFICATE